

Ventilation Guidelines for Professional Installers

HPS10 models 4065452, 4842214 & 5207971 HPA10 models 5374506, 5374507, 5374512 & 5374513 HPV10 models 5374508 & 5374510						
Configuration	Enclosed Room	Fully Louvered Door	Upper and LowerLouvers in Door (Note 1,2)	Upper Louver and Undercut Door (Note 1,3,4)	Inlet <u>or</u> Outlet Ducting and a Single Louver or Undercut Door (Note 1,3,4,5)	Inlet <u>and</u> Outlet Ducting (Note 5)
Minimum Space (FT ³)	450	84	84	84		
Space Example L x W x H (FT)	6 x 7.5 x 10	3 x 2.8 x 10	3 x 2.8 x 10	3 x 2.8 x 10	No minimum space requirement	No minimum space requirement

450 ft³ enclosed room size is 35% smaller than other manufacturers require

- Note 1: Minimum louver size is 130 in ² free area each.
- Note 2: When two louvers are installed, install one louver at the top of the heater and the other close to the floor.
- Note 3: Undercut door should have a minimum of 0.75" clearance. (minimum 18 in ² air gap)
- Note 4: When one louver is installed, install the louver in a location close to the top of the heater.
- Note 5: This heater supports multiple duct diameters as well as rigid and flex ducting options. See manual for more information.

HP10 models Lowe's Items: 816193 & 816194						
Configuration	Enclosed Room	Fully Louvered Door	Upper and Lower Louvers in Door (Note 1,2)	Upper Louver and Undercut Door (Note 1,3,4)	Inlet <u>or</u> Outlet Ducting and a Single Louver or Undercut Door (Note 1,3,4,5)	Inlet <u>and</u> Outlet Ducting (Note 5)
Minimum Space (FT ³)	450	84	84	84		
Space Example L x W x H (FT)	6 x 7.5 x 10	3 x 2.8 x 10	3 x 2.8 x 10	3 x 2.8 x 10	No minimum space requirement	No minimum space requirement

450 ft³ enclosed room size is 35% smaller than other manufacturers require

- Note 1: Minimum louver size is 130 in ² free area each.
- Note 2: When two louvers are installed, install one louver at the top of the heater and the other close to the floor.
- Note 3: Undercut door should have a minimum of 0.75" clearance. (minimum 18 in ² air gap)
- Note 4: When one louver is installed, install the louver in a location close to the top of the heater.
- Note 5: Ducting these models requires adapter kit 100234320. Duct with 8" flex duct. Maximum 50 equivalent feet for total of inlet and outlet ducting.